

ASSEMBLY INSTRUCTIONS

SSOS2

IMPORTANT NOTES

The water can flow in many forms and patterns on any of the stainless steel water features. A sheer fall of water is possible but will never be constant. Please allow 2-3 days for the water to settle.

DO NOT expect the water to cover 100% of the feature, but remember the better you level your feature, the better the water coverage.

If you require a mainly sheer fall of water then we recommend washing the stainless steel feature with Viakal (bathroom lime scale remover) to remove any oil or lime.

If the water gives excessive splash, you can always use a piece of plastic sheet, to go a little wider than the base liner under the rocks.

It may help to keep your water and feature clean, if you add a chlorine tablet or pre wash with a bathroom cleaner such as 'viacal'.

Our water features are designed for outside use, but can be put indoors if required. The pump supplied may give of some noise if used in a confined space.

ASSEMBLY

1. Using the base liner, mark the ground area that needs to be cleared.
2. Place liner into the hole and spirit level to make sure you have a level base for your feature.
3. Looking at the base of your feature connect your pump ensuring that the cable is passing underneath the liner bracket, Just make sure both pipes are coming out of the base.
4. Place your feature into the liner ensuring that all pipework meets in one area, and is not trapped under any of the legs. Insert bolts 1 into the top holes of your 'S' frame. Bolts 2 are then added to the lower 'S' bolt holes and adjuster A bracket (see diagram). Using a spirit level, on the top edge of the feature, adjust the bolts until the feature is level in all directions. (This may need to be done again in a few weeks once the ground has settled).
5. If you have a tall wall , place the pond pump into the liner and connect the pipework to the outlets on the pump. Run the cable of your feature to the nearest power point for your first test. We recommend that a qualified electrician carries out all electrical work.
6. Fill reservoir with water.
7. Turn your feature on and check to see if you have your desired effect. Once satisfied switch off and add reservoir lid. Decorate the lid with stone, pebbles or rock to give the finish required. Your feature should now be ready for operation. Keep checking the water level over the next few days to see if there is any splashing causing water loss. If so remove any stones that may be causing this problem.

IMPORTANT!!!

If your feature is going to be free standing, then it must be secured to the ground.
Stainless surrounds can be pushed over base once fixed down.

